

Download Pachislo Slot Machine Service Manual

Machines with 4 or 6 reels On a pachislo slot machine the additional reels let you know when you are about to win they do not increase the payout. Some do it with LCD's / a fourth reel – or with WIN lights such as on the Babel machine. ALL 4th REEL MACHINES - The 4th reel only spins to indicate you are going to Unpack the pachislo from the carton and confirm the following items are included: 1. A pachislo machine The pachislo weighs about 85 lbs. Please pick it up carefully! 2. Tokens 3. Door and reset keys 4. Extra light bulbs (If required, many new machines are LED only) 5. Coil key chain 6. Owner's manual Getting Started 1. Pachislo Slot Machine Operation Manual 4 STEP 5 – WINNING COMBINATION If a winning combination is "HIT", the corresponding win will automatically be paid out by the hopper or credited to the machines CREDIT display meter. If there are no credits on the CREDIT METER, insert 1-3 tokens to repeat game play. STEP 6 – BET/MAX BET button Page 1 Pachislo Slot Machine Operation Manual Locate the payout hopper and remove it from the machine. If the hopper is connected to a wire harness be sure to disconnect it first. Also, some machines have a mechanism located at the base of the hopper to help hold it in place.